

N EMD SD-60 DIESEL LOCO CHINA

ORDER PARTS ➔

INSTALLATION OF WINTERIZATION HATCH

- 1) Remove fuel tank by pulling it off the frame.
- 2) Grasp frames in the area where the fuel tank was and pull the entire body off the frames. Remove air horn from cab to avoid damage, and put in a safe place.
- 3) Using a sharp hobby knife or razor blade, remove the 2 lift rings indicated.
- 4) Turn body upside down and locate the 3 dimples on the top of the shell. Open these using a #74 (.02250) drill bit in a pin vise.
- 5) Install winterization hatch, using super glue to attach from the inside if permanent installation is desired.
- 6) Reassemble the loco by reversing the above steps.

