


INSTALLING THE AUX CONNECTION J4 FOR TURNOUT INDICATION & 21ST CENTURY SIGNAL SYSTEM



THE "AUX" TERMINAL CONNECTION LOCATED ON J4 PROVIDES THE INTERFACE TO CUSTOM SIGNALS TURNOUT CONTROL MODULE. THIS INPUT IS REQUIRED TO GIVE THE SWITCH TURNOUT CONDITION "T" OR "THROUGH/STRAIGHT" OR "OUT" "DIVERGING" ROUTE. FOR SIGNAL INSTALLATIONS WHERE THE TURNOUT SETTING IS USED TO CONTROL THE CIRCUITRY REQUIRED TO SIGNAL TRACK CONFIGURATIONS USING INTERLOCKINGS TYPICALLY AT PASSING SIDINGS CROSSOVERS ETC. VISIT CUSTOM SIGNALS WEBSITE TO PLAN YOUR SIGNAL INSTALLATION USING HIS TRACK CONFIGURATION LIBRARY.

