EMD SD-9 DIESEL LOCO

ORDER PARTS



LIMITED WARRANTY

Atlas Model Railroad Co., Inc., warrants that this locomotive will be free from defects in material and workmanship for a period of ninety (90) days from the date of purchase. If this locomotive fails during the warranty period, carefully pack the assembled item in the original carton, together with the dated sales receipt, and return to: Atlas Model Railroad Co., Inc., 378 Florence Ave., Hillside, N.J. 07205. Defects due to misuse, improper maintenance and/or abuse are not covered by the warranty. Items that have been disassembled by the modeler or anyone other than an authorized Atlas repair person are not covered by the warranty. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

NOTE

1) Maximum operational voltage 12V DC

Remove screw from knuckle coupler and then remove coupler. Position coupler spring in retainer as shown below. Then slide Rapido coupler into sill opening. While holding in position, slide retainer so center pin goes through hole in coupler. Push down until it snaps into place.



N SCALE

1172-PI01